



IDS Lift-Net Tech Support

Lift-Net Computer Setup - Auto-Recovery

Refer to the computer manual for access to BIOS settings. Refer to Windows documentation for Windows settings.

1. Configure computer BIOS to turn computer ON when power is restored after an outage.
2. Configure Windows for local date and time. Important for correct Lift-net reports. Select Auto Daylight Savings Time if applicable.
3. Network machines only. Configure Windows IP Address, Subnet mask, and gateway.
4. Configure Windows screen resolution for 1024 x 768 minimum.
5. Configure hard drive to NEVER shutdown.
6. Disable screen savers. Most are memory hogs and may interfere with Lift-Net data collection.
7. Configure monitor to turn off after (user selectable) usually 1 hour.
8. Share the lift_net folder.
9. Configure Windows to Boot without requiring a password. Password is entered once by an administrator and is not required again.
10. Copy the Lift-Net Monitoring program to the Windows Startup folder.

When the steps outlined above have been completed, the computer should automatically boot-up and run the Lift-Net program when power is restored after a failure.